






# INSTRUCTION



## External RH sensor for CDP-(T)/CDF 40-50-70









1




# 2




# 3




4




5




# 6




# 7




# 8




# 9




# 10




# 11




# 12




# 13




# 14




15




16




17



# 18



# 19





052506